OPERATING CONTROLS

(1) Shutter Release Button

(2) Film Counter

(3) Meter On/Off Switch and Shutter Lock Control

(4) AE(EE) Position

(5) Self-Timer/Depth-Of-Field Preview Lever

(6) Self-Timer Lock Release

(7) Depth-of-Field Scale

(8) Distance Scale

(9) Manual Aperture Selection Scale

(10) Konica Hexanon Lens

(11) Focusing Ring

(12) Aperture Control Ring

(13) AE Release Button

(14) Film Transport Lever

(15) Film Speed Indicator Window (DIN)

(16) Film Speed Indicator Window (ASA)

(17) Shutter-Ready Indicator

(18) Multiple Exposure Lever

(19) "X" Synchronization Hot Shoe

(20) Shutter Speed Scale

(21) Film Plane Mark

(22) Shutter Speed Dial

(23) Film Transport Indicator

(24) Film Rewind Crank

(25) Flash Cord Terminal (M, X)

(26) Neckstrap Eyelet

(27) Lens Mounting Index Mark

(28) Lens Lock Release Button